

# DURALUX HIGH OUTPUT LED WORKLIGHT

Installation Instructions & User's Manual





VISIONXLIGHTING.COM 🚹 🗃 🔂

## **VISION X**

## <u>DURA-4:</u>



USSER

#### **FEATURES**

- 1. Four 5-watt LED Produces 2,150 Lumen
- 2. Single Bolt mounting for easy & universal installation
- 3. High Pressure spray IP-69K waterproof

#### XIL-OPR110 SERIES SPECIFICATIONS

- 1. Warranty
- : Extended
- 2. Housing Colors : Black
- 3. Amp Draw : 1.67A (12V)
- 4. Input Voltage : 9-32V
- 5. LED Lifespan : 50,000 Hours

#### PREPARATION


- 1. We recommend completely reading instructions before installing.
- 2. Consult your local state regulatory agency regarding the use of LED lighting.
- 3. The placement of LED lighting should not restrict airflow to the radiator, or block head lamps, turn signals, or parking lights.

#### MAINTENANCE

1. All Vision X models have been designed for maintenance free use. In the case an LED lamp or other part replacement is needed please contact your authorized service center.

**TIP:** For complete application guide see Website





#### WARNINGS

As with many other high-tech products, this VISION X LED requires a bit of attention before you can use it. Please read the accompanying information carefully first.


- 1. Don't stare directly into the light or shine directly into the eyes of another person as this may cause temporary loss of vision.
- 2. Never disassemble the products, as all parts must be factory serviced to insure proper operation.
- 3. Don't interchange the parts inside this light with other products.
- 4. The LED light is to be mounted on the vehicle only in a vertical, bottom mounting, or in a suspended position.
- 5. After turning on the light, the body might be hot enough to warrant a burn risk. Be careful when you touch the body after turning on the light for a long period of time.
- 6. Use the supplied wire harness for electrical installation.
- 7. The LED light must not adversely affect the performance of low beam, high beam, engine cooling or the driver's view.

#### MANUFACTURER RECOMMENDATION

For those unfamiliar with electrical wiring on vehicles, Vision X recommends that all LED Lighting products are professionally installed.

#### WIRING INSTALLATION

- 1. Disconnect your battery before instal.
- 2. Find the factory fog Light harness or an existing power source, to tap into.
- Connect the positive (red) Pigtail wire to the positive wire of your previous wiring harness. Repeat this step for the negative Pigtail (black) wire as well.
- 4. Once the Pigtail is connected to the factory wiring harness, its ready to plug into the LED Light for use.




WARNING: Bolts, Nuts, and Washers are Stainless Steel. <u>DO NOT USE</u> Pneumatic or Electric Tools to Tighten and Loosen. The <u>Hardware Will</u> <u>Permanently Lock Together</u>.



#### **MOUNTING INSTALLATION**

- 1. First, place the Light on the location where it will be mounted. Remember that it must be within reach of the harness.
- 2. Next determine where the (M8) bolt will be placed, and mark where the bolt locations will be.
- 3. Drill a hole for the (M8) bolt.
- 4. Place the Light over the hole, and slide the bolt through. Washer is then applied on the other end of the drilled hole followed by the bolt.
- 5. Tighten nut to desired tightness.





### You May Also Be Interested In:



Part # - 4000322 Item # - XIL-SRECEIVER Tow Hitch Mount



Flush Mount Ideal for bumpers



**Pro Pods** Available in multiple colors



Part # - 9893372 Item # - XIL-C200 Clamp Tube Mount (0.75"-3.0" Diameter Available)



Part # - 9897349 Item # - XIL-SN06 Security Hardware



VISIONXLIGHTING.COM 🚹 🛅 🔂